

MID AMERICA



MOTORWORKS

Pursue your passion here

Suggested Installation Instructions for:
310-959 Wiring Kit for VDO Tach

DESIGNED FOR USE WITH ALL VDO ELECTRONIC TACHOMETERS ON ENGINES WITH BREAKER POINT IGNITION.

- 1.) Connect terminal #2 to a switched 12 volt power source (switched by ignition key)
- 2.) Connect terminal #3 to ground
- 3.) Connect terminal #4 to negative (-) side of coil using special connector 310959S
- 4.) Set the 3 switches as follows: Looking at the back of the instrument, place the switch on the right side in the up position. The other 2 switches should be placed in the down position.