

MID AMERICA**MOTORWORKS**

Pursue your passion here

Suggested Installation Instructions for:
601-895, 1970 Auto Bulb Kit for Corvettes – 12 Volt (42 pcs.)

This kit contains the following:

<u>LOCATION</u>	<u>QTY</u>	<u>BULB#</u>
Front Parking/Turn Signal Lamps	2	1157NA
Rear Parking/Turn Signal Lamps	4	1157
Backup Lamps	2	1156
License Plate Lamp	1	97
Front/Rear Side Marker Lamps	4	168
Clock Lamp	1	1895
Radio Lamp	1	1893
Courtesy Lamps	2	631
Dome Interior Lamps	2	211
Cigarette Lighter Lamp	1	1445
Glove Compartment Lamp	1	1895
Heater & A/C Lamp	1	1816
Luggage Compartment Interior Lamp	1	90
*Turn Signal/Hi-Beam Indicators	3	1895
*Door Ajar Lamp	1	1895
*Instrument Panel Lamps	13	1895
Seat Belt Warning Indicator	1	194
Brake System Alarm Indicator	1	1895
*indicates in-dash installation		