

MID AMERICA



MOTORWORKS™

Pursue your passion here®

Suggested Installation Instructions for Product Number:

#603-610

1992-1996 Chevrolet Corvette - LT1 Rectangular Exhaust Extensions

Note: These MAD-Exhaust tips are designed to slide over the existing stock 92-96 LT1 Exhaust Tips.

1. Slide the new exhaust tip over the stock exhaust tip with the mounting holes facing towards the ground.
2. After adjusting the tip to the desired length, make sure the tip is square with the car.
3. Hold the exhaust tip in place and drill two holes using the holes in the new tip as a guide.
4. Tighten the screws while making sure the new tip remains straight.
5. Check for any noise rattle and retighten the exhaust tips if necessary.

Mid America Motorworks, #1 Mid America Place, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 • www.mamotorworks.com • mail@mamotorworks.com

Form #600352-081211 Copyright 2009 Mid America Motorworks