

MID AMERICA



MOTORWORKS™

Pursue your passion here®

Suggested Installation Instructions for Product Number:

634-343, 2005-2009 Corvette Side Marker Light Bezels

634-344, 2006-2009 Corvette Side Marker Light Bezels

Count on Mid America Motorworks for all your Corvette Parts and Corvette Accessories

PARTS INCLUDED:

___ 4-Stainless Side Marker Bezels

___ 2-Adhesive Promoter Tubes

Your side marker bezels are designed to go around your side marker lights and attach directly to the painted surface.

1. Clean the area around each of the side marker lights with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.
2. Place each bezel into position to familiarize yourself with each placement before removing the liner. It WILL BE necessary to HAND FORM the bezels to CONFORM to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each light. Press firmly to set.

DO NOT GET WET FOR 24 HOURS.