

Application: 1984 - 1996 Corvette

INSTRUCTION SHEET

Part Number



Part Includes

1 - Hatch Vent Assembly

Corvette Hatch Vent



STEP 1.

Remove bolt from Hatch Vent using a T-40 Torx bit screwdriver or wrench.

STEP 2.

Slide Hatch Vent onto existing rear hatch latch assembly.

STEP 3.

Using the T-40 Torx bit screwdriver or wrench, insert and tighten bolt securely until there is no shake or rattle of the Hatch Vent on the latch assembly.

STEP 4.

Carefully ease the rear hatch closed. To prevent damage to the vent of your vehicle, D0 NOT SLAM.





R



@CorvettePassion

MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

CorvettePassion