



**Application:** 1991-1996

**Part Includes**

1- (2) Custom Fit Splash Guards

## Splash Guards, Rear



**Tools Needed**



**STEP 1.**

Install mounting tab on each flare using 3/8" phillps machine screws and kep nuts. Bend tab so it will lie flat on fender surface.

**STEP 2.**

Note proper alignment of flare making sure it is square with the car. Use a rough file to make notches required to clear non standard trim such as fender well chrome trim.

**STEP 3.**

Remove tire if neccessary and fasten the guard where any existing wheei hoies lime up with the flare holes using metal screws and clip nuts.

**STEP 4.**

Drill remaining wheel and bottom fender holes using a 9/64" bit. Install remaining self tapping sheet metal screws.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**www.mamotorworks.com • generalmail@mamotorworks.com**

©Mid America Motorworks, Inc. All rights reserved.