



Application: 2005-2013 C6 Corvette

Part Includes

1 – Billet Exhaust Plate

Billet Exhaust Plate



Tools Needed



Search: **Exhaust**
www.mamotorworks.com

STEP 1.

Locate bracket screws (2) directly above mufflers. (see figure 1)

STEP 2.

Remove both screws (see figure 2)

STEP 3.

Move one of two brackets outwards and align the screw holes on the other bracket. Re-fasten screw into bracket only fastening it half way into the hole.

STEP 4.

Take exhaust plate and slide the upper part of the plate over the exposed screw. Do not fasten screw completely yet. Repeat steps 3-4 for the other bracket. (see figure 3)

STEP 5.

After the exhaust plate is in position with the stock screws, move the exhaust plate left or right in order to center it between the exhaust tips. (see figure 4).

STEP 6.

Once the exhaust plate is centered to your liking, fasten the bracket screws securely to avoid any rattling sounds.



Figure 1.



Figure 2.



Figure 3.



Figure 4.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.