



Application: 2005-2013 C6 Corvette

Part Includes

- 1 - Stainless Tag Back
- 1 - Chrome Tag Frame
- 2 - 6mm Hex Head Bolts
- 2 - Chrome Push-On Top Hats
- 2 - Flat Black Vinyl Graphics

Tag Back/Frame



Tools Needed



Search: **License Plate**
www.mamotorworks.com

STEP 1.

The new license plate frame comes to you with a set of flat black vinyl graphic back drops. These are supplied to be placed directly to the paint just in back of the frame grille areas to simulate a real vent opening. To utilize these, place the frame in position and mark the grille mesh or perforated locations through the grille directly onto the paint. Remove the frame then carefully peel the vinyl from the paper sheet and apply the graphic to the paint at both locations. Then install the frame.

This is the most simple and straight forward way to install these graphic inserts; however, if you find this method to be a little tricky, try this:

Apply the back drops wet. This will allow the inserts to slide around to the best position and then squeegee out the fluid to set the graphic. To do this, mix a 32oz spray bottle of water with a few drops of Johnson's Baby Shampoo. Spray the solution to the paint and make sure the mixture sheets the paint and does not bead up. Once a good solution has been achieved, spray the car as well as the graphic and slip the insert into position. Then, squeegee it to set in place.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.