



**MID AMERICA  
MOTORWORKS™**

## INSTRUCTION SHEET

*Part Number*

**630-565**

**Application:** 2005-2013 C6 Corvette

**Part Includes**

2 – Stainless Mirror Trim Rings

# Side Mirror Trim Rings



### Tools Needed



Search: **Mirror**  
[www.mamotorworks.com](http://www.mamotorworks.com)

### STEP 1.

Thoroughly clean mirror glass and perimeter with alcohol to remove any dust, dirt, and wax.

### STEP 2.

Before permanently attaching the trim ring, set it onto the mirror to get an idea of how it will set in place and the overall shape. Although it should not be necessary, adjustments to the perimeter shape may need to be made so that it matches the mirror's edge perfectly. The stainless is very thin and will allow any adjustments very easily. TIP: Should any adjustments be necessary, set the trim ring on a flat surface such as a counter top. This will help prevent the trim ring from warping out of shape and will keep the ring remain flat.

### STEP 3.

Slowly remove the release liner from the back of the trim ring and carefully set the ring in place pressing firmly along the entire perimeter to set the ring. Pressing firmly along the edge is very important to achieve a long lasting bond.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401  
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800  
[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)  
©Mid America Motorworks, Inc. All rights reserved.