



Application: 1997–2004

634-347



Search: **Exhaust Systems**
www.mamotorworks.com

Part Includes

- 1–Stainless Panel
- 2–Small Self Tapping Screws

Exhaust Surround



Tools Needed



NOTE: Your new exhaust port filler panel is designed to fit over the exhaust and is sandwiched between the exhaust pipes and the urethane bumper. (See Pictures 3 & 4) Your new panel comes to you with a protective liner. Do not remove until your installation is complete!

STEP 1.

Your new panel comes to you flat – in order to achieve a nice snug fit it will be necessary to slightly curve the filler panels' left and right side. (See Picture 2).

STEP 2.

Carefully place your filler panel over the exhaust pipes until it reaches the black fiberglass underbody between the pipes. With your forefinger, force the bottom section of the filler panel until the bent tab snaps under the car. (See Pictures 3, 4, 5 & 6).

STEP 3.

At this point the panel fits pretty snug. You will notice slight gaps at the right and left corners. Simply pull the panel to form its shape until it contours to the shape of the car. (See Pictures 7, 8, 9 & 10).

STEP 4.

Once you are satisfied with the shape line up your panel so that it sits in the center and your right and left corners line up with the urethane bumper. (See Picture 11).

STEP 5.

You have been provided with two washer head self-tapping screws. Fasten your filler panel in position at the two mounting holes located at the underside of the panel. (See Picture 12 & 13).

STEP 6.

Complete your installation by removing your protective liner. (See Picture 14).

Note: Care must be taken when cleaning your panel. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe using a new clean soft cloth with a good quality streak free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



634-347

Exhaust Surrön, No Emblem



1.



2.



3.



4.



5.



6.



7.



8.



9.



10.



11.



12.



13.



14.