



**Application:** 2008-2013 Corvette

**Part Includes**

- 1 - Stainless 2pc Radiator Cover
- 1 - Adhesive Promoter Pack
- 2 - Lengths of Velcro Attachment Tape

## 2pc Radiator Covers



**Tools Needed**



Search: **Radiator Covers**  
[www.mamotorworks.com](http://www.mamotorworks.com)

Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed

**INSTALLATION INSTRUCTIONS.**

Your new cover comes to you preformed however it will be necessary to further shape the part by hand in order to achieve a nice custom fitted accessory.

**STEP 1.**

Thoroughly clean the top of the factory black plastic radiator cover with household rubbing alcohol to remove any and all grime and dirt. Then swipe the top back edge of the factory cover closest to the motor with the adhesive promoter provided. Pull up on the air filter tube cover especially at the large air capacitor front grommet far enough to remove the small black plastic retainer. The retainer is actually a 2-part unit, to remove it you will need to pull the very top head of the retainer this is a plastic nail so to speak, which plunges into the lower section spreading it into the factory radiator cover locking it in place. By pulling up on this top section you will be able to release the entire retainer.

**STEP 2.**

You have been provided with two lengths of Velcro attachment tape. Place the two lengths directly to the edge of the factory cover you just prepared. Press firmly to set. Expose the tapes adhesive edge so that the top section of the tape will attach to the new cover once it is set in position.

**STEP 3.**

You will notice a large rubber grommet securing the air tube to the factory radiator cover. Starting with the passenger side slide the stainless cover notch directly under the air tubes ear so that it will rest between the grommet and the air tube. Slide it completely in and set it down so that it will come into contact with the attachment tape installed earlier and press firmly to set. Lift the cover off the mounted attachment tape and remove the cover. Firmly press the attachment tape securely to the underside of the new cover. This will create a nice permanent attachment.

**STEP 4.**

Reinstall the cover and adjust its position to achieve a nice straight final position. Make sure the small hole in the cover lines up with the retainer hole. Once the cover is in place replace the factory retainer. Repeat the procedure for the opposite side. Remove the protective liner then firmly press the entire air tube assembly to snap back in place over the plastic retainers.

**Note:** Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.