



Application: 2006-2013 Corvette C6



Search: **Spoilers**
www.mamotorworks.com

Part Includes

1 - ZR1 Style Chin Spoiler

ZR1 Style Chin Spoiler



Tools Needed



Typical installation time will range from 20 minutes to 60 minutes depending on equipment available. With a car lift you can complete in 20 minutes, however with a floor jack allow 60 minutes.

STEP 1.

Get your C6 off the ground. Either with a floor jack or a car lift. Be sure to block the back tires as well as engaging the safety brake.

STEP 2.

You will need to remove your stock lower plastic/rubber front rub spoilers. These come as a 3 piece set up. You only have to remove the 2 outside pieces. The center piece is optional to remove. These simply unbolt.

STEP 3.

Next, dry fit your spoiler to your C6. This is much easier with the help of a friend. You'll want to fit it front to back as well as side to side.

STEP 4.

Once you have noticed how the spoiler sits, set it back down.

STEP 5.

Using rubber alcohol, clean the lower bumper area to remove all wax, grease and grime. Allow to dry for 2-3 minutes.

STEP 6

With the provided 3M tape, take off the backing to show the adhesive part of the tape. This isn't used to secure the splitter, this is used to keep the splitter tight and flush for the life of your car.

STEP 7.

Push your new splitter up into place, drill your holes and install your bolts.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.