



Application: 1984-1996 C4 Corvette

Part Includes

- 1 - Pair Driver Side Stripes
- 1 - Pair Passenger Side Stripes

Fender Accent Stripes



Tools Needed



Before you begin installation, be sure to thoroughly clean your fender. Remove all dirt, grime and buildup from the fender for best results.

NOTE: It may take up to 2 hours for the stripes to completely dry after you have positioned them on your fender. Do not drive your Corvette until the stripes are completely dry. Do not leave your Corvette in the sun while the stripes dry, as it will cause more bubbles.

NOTE: For emergency removal, use a heating device or a good hair dryer to take the stripes off your fender.

STEP 1.

Make sure your Corvette is clean and the fender is free of silicone or tire wet spray. Park on a level surface out of the sun.

STEP 2.

Begin with the driver side fender. Do a dry run before peeling the backing paper from the vinyl stripes. Lay the stripes on the fender in the position desired. The stripes are cut slightly different to fit the fender in the forward or rear position. The emblem or script is on the forward stripe.

STEP 3.

Once the proper location has been chosen, gently peel the backing paper from the decal. Spray glass cleaner such as MWorks Glass Cleaner **119-033** on the fender as well as the decal itself.

STEP 4.

Gently place the decal in position beginning at the fender edge and working toward the hood. The glass cleaner allows you to "float" the decal into position.

STEP 5.

Repeat with the second decal. When both stripes are applied, make sure they are parallel to each other.

STEP 6.

Gently squeegee out all the water and creases. If the stripe starts to dry in the wrong position, rewet the fender and stripe, then reposition.

STEP 7.

Continue with squeegee until all the bubbles and creases are removed and the stripe is dry. For better results, wrap your squeegee in a small towel and lay it flat on the surface and continue to remove any bubbles. You may have to repeat the process for 10-15 minutes until all the bubbles are removed and the stripe is dry.

STEP 8.

Repeat steps 2-7 for the passenger side. Let the stripes completely dry for an hour or two before driving the vehicle.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.