



**MID AMERICA  
MOTORWORKS™**

## INSTRUCTION SHEET

*Part Number*

**602-843**

**Application:** Corvette 1997-2001

**Part Includes**

1 – Pair of Sill Protectors

# Clear Sill Protectors



### Tools Needed



Search: **Carpet Sets**  
[www.mamotorworks.com](http://www.mamotorworks.com)

**INSTALLATION IS A SIMPLE "PEEL AND STICK" PROCEDURE.**

#### **STEP 1.**

Remove wax buildup from area to be covered.

#### **STEP 2.**

Remove red backing from clear double stick tape.

#### **STEP 3.**

Remove fingerprints from underside of sill protector.

#### **STEP 4.**

Press in place and remove air bubbles by pressing to outer edge.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
©Mid America Motorworks, Inc. All rights reserved.