



**MID AMERICA
MOTORWORKS™**

INSTRUCTION SHEET

Part Number

606-161

Application: 1997-2013 C5

Part Includes

1 - Component

Aluminum Dead Pedal Cover



Tools Needed



Search: *Interior Trim, Door Panels, Sunvisors*
www.mamotorworks.com

STEP 1.

Thoroughly clean dead pedal area before installing new unit to promote good adhesion.

STEP 2.

"Dry" position the C5 Corvette Aluminum Dead Pedal Cover for centering.

STEP 3.

Peel backing paper from adhesive tape.

STEP 4.

Position aluminum dead pedal cover over factory dead pedal area and press into place.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.