



Application: 1984-1996

Part Includes

1 - Automatic Transmission Shift Knob

Automatic Transmission Shift



Tools Needed



Search: *Dash & Center Console*
www.mamotorworks.com

NOTE: Wear Safety glasses during this installation, particularly in Steps 2 and 5.

STEP 1. Using the screwdriver, gently pry shift button and mounting clip up and out of shift knob to reveal shift lever rod.

STEP 2. Looking down onto shift lever rod, use snap ring pliers to remove "C" snap ring. Keep one hand free to grasp the snap ring immediately upon removal as this spring-steel snap ring is prone to taking flight!

STEP 3. Remove shift knob by pulling upward on knob. Note: Knob may be seated very tightly, continue to wiggle the knob while pulling upward.

STEP 4. Install new shift knob, using heavy downward force to properly seat the new knob, so that snap ring channel on shift lever rod is in view.

STEP 5. Carefully reinstall snap ring. Hint: Using snap ring pliers, spread snap ring apart then cup your hand around the snap ring and shift knob opening in case the snap ring slips off the pliers.

STEP 6. Reinstall button and mounting clip. With engine OFF, turn key to "Accessories" position to check operation of shifter in all gears. (DO NOT START VEHICLE.) If shifter will not come out of Park, the shift knob is not seated, return to step 4.

Auxiliary Button Cover Installation (Only for 603-166 and 603-168):

Simply snap new button over the factory shift button. Adhesive is optional but not necessary, as it may mar your factory shift button.



603-164



603-166



603-168



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.